NOTES TO DESIGNER

- 1 REFER TO LANL FACILITY CONSTRUCTION SPECIFICATIONS SECTION 15185.
- 2 REVIEW DETAILS AND REVISE AS NEEDED TO SUIT PROJECT REQUIREMENTS.
- 3 COOLING TOWER DESIGN CONDITIONS:

WATER IN (TWR) 85° > 10° TD RANGE
WATER OUT (TWS) 75° > 75° TD APPROACH

4 TOWER PUMP FLOW:

GPM CIRCULATED = $\frac{\text{SYSTEM LOAD (BTUH)}}{500 \times (\text{T 'F (TWR)} - \text{T 'F (TWS)})}$

COOLING TOWER WATER EVAPORATION:

GPM EVAPORATED = GPM CIRCULATED X TD RANGE X 0.0008

SEPARATOR BLOW DOWN (DRAIN):

GPM CIRCULATED = $\frac{\text{COOLING TOWER GPM EVAPORATED}}{\text{NUMBER OF CYCLES} - 1}$

CYCLES = RATIO OF TOTAL DISSOLVED SOLIDS (TDS) OF TOWER WATER DIVIDED BY TDS OF MAKE-UP WATER. BASE CALCULATION ON CYCLES = 2.5

- 7 SYSTEM NON-POTABLE MAKEUP WATER (NPMW): NPMW = GPM EVAPORATE + GPM BLOW DOWN
- 8 CHECK NPSH REQUIRED FOR COOLING TOWER PUMP VERSUS NPSH AVAILABLE.
- 9 SPECIFY STRAINER DOWNSTREAM OF COOLING TOWER PUMP.
- 10 SPECIFY BALL TYPE SHUTOFF VALVES FOR SIZES 2" AND SMALLER AND BUTTERFLY TYPE FOR SIZES 2 1/2" AND LARGER. USE LUG BODY STYLE BUTTERFLY VALVES, BOLTED FOR DEAD END SERVICE, WITH GEAR ACTUATOR.
- 11 UNIONS ARE NOT REQUIRED FOR FLANGED VALVES AND CONNECTIONS.
- 12 SEPARATOR:
 - A SIZE SEPARATOR FOR 10% OF SYSTEM FLOW.
 - B MINIMUM INLET PRESSURE SHOULD BE AT LEAST 15 PSI OR EQUAL TO THE PRESSURE LOSS ANTICIPATED THROUGH THE SEPARATOR PLUS THE SYSTEM DOWNSTREAM PRESSURE REQUIREMENTS.
 - C SPECIFY A FLANGED SPOOL PIECE ON THE OUTLET OF THE SEPARATOR IN ORDER TO REMOVE THE UPPER FLANGED DOME FOR MAINTENANCE. REFER TO THE MANUFACTURER'S CATALOG DATA FOR RECOMMENDED SPOOL PIECE LENGTH.
 - D PIPE CONNECTIONS TO THE INLET AND OUTLET OF THE SEPARATOR SHOULD BE A STRAIGHT RUN OF AT LEAST 5 PIPE DIAMETERS (INCLUDING OUTLET SPOOL PIECE) TO MINIMIZE TURBULENCE. NOTE THE STRAIGHT PIPE LENGTH ON THE PIPING DRAWINGS. RECOMMENDED DIRECTION OF INLET/OUTLET PIPING TO CONTROL VIBRATION:

12 SEPARATOR (CONT)
INLET
OUTLET

- 13 SIZE COOLING TOWER DRAIN AND OVERFLOW PIPING TO MATCH COOLING TOWER CONNECTIONS.
- 14 LOCATE FLOOR DRAINS CLOSE TO COOLING TOWER CONTROL SYSTEM
- 15 LOCATE CONTROL CABINET AND CHEMICAL TANKS IN AN ACCESSIBLE AREA SO SYSTEM CAN BE MAINTAINED AND DRUMS REPLACED.
- 16 REFER TO SECTION 204 IN THE MECHANICAL CHAPTER FOR WATER DISCHARGE REQUIREMENTS.

